

Instruction:

- (1) Fix one side of glass clamp on the bar, glass, wall or floor.
- (2) Base on the thickness of glass, put the rubber pad on both side of glass (between glass and clamp)
- (3) Assemble another side of glass clamp and screw tightly with another side of clamp to hold the glass tightly.
- (4) For #3500-01F, it has one more screw (M6*8.0). After above processes, this screw would fasten the glass more firmly.

Note for Mounting screws:

In the order, we do not offer following screws. Please prepare when fixing.

If clamp fixing on the wall, use general screw (as for standoffs). Be sure the diameter screw head is larger than the fixing hole (as below diameter)

If clamp fixing on the bar, use Hex socket cap screw (as below drawing)

#3500-01F

